

DEI-104J-230V Operation Manual

Version 01
5INSL00296

1. CAUTION :

- 1.1 Before wiring, please make sure that power is switched off to prevent from getting electric shock.
- 1.2 The product should be avoided to install at humid environment.
- 1.3 To prevent the controller burning out, please make sure the water - proof procedure is undertaken during installation.
- 1.4 Before supplying the power, please always check if the wiring and input power is connected correctly.
- 1.5 Please install according to the wiring diagram, in order to avoid incorrect wiring.
- 1.6 Please always read this instruction carefully before installation. This product is beyond our warranty if any damage is caused by incorrect wiring.

2. SPECIFICATION :

- 2.1 Front panel size : 34.5mm (H) × 76mm (L) ± 2mm
- 2.2 Mounting hole size : 30mm (H) × 72mm (L) × 85mm (D) ± 1mm
- 2.3 Operating environment temperature : -5°C ~ 55°C , <90%RH (non - condensing)
- 2.4 Storage environment temperature : -10°C ~ 65°C , <90%RH (non - condensing)
- 2.5 Power supply : AC230V ± 10% , single phase 50 / 60Hz
- 2.6 Power consumption : Max. 10 watts
- 2.7 Temperature sensing / display range :
 - 2.7.1 -40°C ~ 55°C , accuracy ± 1°C , in 0.5°C step.
 - 2.7.2 -40°F ~ 131°F , accuracy ± 2°F , in 1°F step.
- 2.8 Output / Input :
 - 2.8.1 Sensor : NTC , 1.5m (L)
 - 2.8.2 Compressor output contact : 40(9)A / 230VAC
 - 2.8.3 Alarm output : Buzzer (Optional for purchase)

3. FUNCTION :

- 3.1 Button operation :
 - 3.1.1 Setup mode : In power on status, press and hold **[Set]** key for 3 seconds to enter setup mode, display showing "tS".
 - 3.1.1.1 View Parameter values : When parameter code is shown in display, press **[Set]** key to view parameter values.
 - 3.1.1.2 Select parameter code : When parameter code is shown in display, press **[▲]** or **[▼]** key to select parameter codes.
 - 3.1.1.3 Parameter adjustment : When parameter value is displayed or under rapid setup mode, press **[▲]** or **[▼]** key to adjust parameter value. Whenever there is a switch in °C and °F readout, the controller will restore to their default values.
 - 3.1.2 Rapid setting : In power on status, press and hold **[▼]** key for 3 seconds to enter rapid setting mode.
 - 3.1.3 Enable / Disable defrost manually : In power on status, press and hold **[▲]** and **[▼]** key s simultaneously for 3 seconds to enable / disable defrost manually.
 - 3.1.4 Parameter lockup : In normal status, press **[Set]** and **[▼]** key simultaneously for 3 seconds to lock or unlock parameter setting. After locked, all parameter values can not be adjusted except "tS".
 - 3.1.5 Enable / Disable Buzzer alarms : When alarms is ON, press **[▼]** key to disable alarm output; Press **[▼]** key again to enable alarm output if failure / malfunction has yet to be eliminated.
 - 3.1.6 Restore default values : Press **[▲]** and **[▼]** key simultaneously before power is supplied to restore default values, display showing "rS". After loading default values, the controller reboots.
 - 3.1.7 Cabinet temperature record : In power on status, press **[Log]** key to view max. temperature or min. temperature record, the display will return to display current cabinet temperature after 5s. Press and hold key **[Log]** for 3s, max. and min. temperature record will be eliminated and they will be both recorded as current temperature

3.2 Function instruction :

- 3.2.1 Compressor operation :
 - 3.2.1.1 Compressor stops operating whenever cabinet temperature reaches the s etpoint (tS) ; the compressor operates when cabinet temperature rises up to setpoint (tS) + temperature differential (td).
 - 3.2.1.2 Compressor delay protection can be set by parameter "AC" . The delay time begins to count down whenever compressor is ready to operate; the compressor would not operate if delay time is not run out. When power is supplied, the compressor output will still delay 1 minute to operate.
- 3.2.2 Defrosting :
 - 3.2.2.1 Enable defrosting :
 - 3.2.2.1.1 Automatic defrosting : Defrosting enables when compressor operation duration up to dF - dt ; If defrosting is enabled manually, defrost period (dt) will not be counted in.
 - 3.2.2.1.2 Manual defrost does not affect the counting of defrost cycle (dF).
 - 3.2.2.1.3 The system starts to count "dt" time after entering defrost mode.
 - 3.2.2.1.4 After defrost period has been finished, controller will automatically load defrost cycle "dF" and begins to count down for next defrost period (dt).
 - 3.2.2.1.5 The system defrosts only once during one defrost cycle.
 - 3.2.2.2 Disable defrosting :
 - 3.2.2.2.1 When defrost period (dt) up.
 - 3.2.2.2.2 Disable defrosting manually will not interfere with defrost cycle.
 - 3.2.2.2.3 Error alarming starts.
 - 3.2.2.3 Defrosting : After defrosting enabled, the compressor output will be disabled. "dt" time will begin to be counted down to terminated defrosting.
 - 3.2.2.4 After reset "dF" or "dt" values, the system will be loading the new values for next defrost cycle.
 - 3.2.2.5 Any failure / malfunction occurred will not affect the time counting of defrost cycle.

3.2.3 Parameter setup :

- 3.2.3.1 Parameter selection : Press **[▲]** or **[▼]** key to select parameter codes in sequence tS, td, dF, dt, AU, AL, HS, LS, Ad, AC, Cr, CS, Ot, Ut, OU.
- 3.2.3.2 Display or reset parameter values : Press **[Set]** to display parameter values after entering parameter setting mode. Parameter value will be increasing or decreasing by holding **[▲]** or **[▼]** key. Press **[Set]** again to save parameter and return to parameter code display. Select "OU" and then press **[Set]** to exit parameter setting and return to normal operation mode.
- 3.2.3.3 Setup mode would be ended and save parameter values without any key pressed within 15s and return to normal operation mode.
- 3.2.4 Rapid setup : when "tS" value blinks in display, press **[▲]** or **[▼]** key to reset "tS" value, press **[Set]** key again or no keys have been pressed in 5s, the system will save the value and return to normal operation mode.
- 3.2.5 Lock parameter : Parameter can't be reset after being locked, but "tS" can be adjusted. When the display shows "LC", it means parameter has been locked; "UL" means parameter is unlocked.
- 3.2.6 Max. and min. cabinet temperature record:
 - 3.2.6.1 When cabinet temperature first time \leq setpoint (tS), the controller begins to record maxi. & min. cabinet temperature.
 - 3.2.6.2 Power failure will not harm for cabinet temperature record, after power is supplied, temperature record will be recalled by controller's memory.
- 3.2.7 Parameter memory : If power failure happens, the controller will operate according to previous parameter values after power is supplied again.
- 3.2.8 Restore default values : The display will be showing "rS" , the controller reboots in 5s.
- 3.2.9 Temperature calibration (Ot) : When there is an aging or inaccuracy occurred on cabinet sensor, users can take this advantage to adjust temperature to a precise temperature.
- 3.2.10 Abnormal temperature alarm : Alarm starts when cabinet temperature exceeds "AU" or drops below "AL" .
- 3.2.11 Circuit board protection : Whenever the temperature of circuit board is out of 95°C (203°F), the controller will disable output contacts compulsively, showing "tA" in display and enabling alarms. Once the temperature of circuit board drops below 75°C (167°F), "tA" will be released.

3.3 LED indicator :

- 3.3.1 Compressor status LED :
 - 3.3.1.1 It keeps dark under setup mode.
 - 3.3.1.2 It blinks rapidly under defrost mode.
 - 3.3.1.3 It keeps bright when compressor is ON.
 - 3.3.1.4 It keeps dark when compressor output is OFF.
 - 3.3.1.5 It blinks when compressor ' s output has yet to reach compressor delay protection time.

4. FAILURE ELIMINATION :

- 4.1 Alarm code :
 - 4.1.1 " UA " : Cabinet temperature \geq AU, UA and cabinet temperature display by turns.
 - 4.1.2 " LA " : Cabinet temperature \leq AL, LA and cabinet temperature display by turns.
 - 4.1.3 " tA " : Circuit board temperature \geq 95°C (203°F), tA blinks.
- 4.2 Error code : Compressor operates with Cr / CS (When Cr and CS are 0, compressor continues operating).
 - 4.2.1 " EE " : Parameter memory failure. To reboot controller, if fails to work normally, send it back to factory for inspection.
 - 4.2.2 " E1 " : Cabinet sensor failure, please try to check if the sensor is well - connected (or replace sensor).
 - 4.2.3 " E3 " : There is a failure / malfunction occurred in circuit board sensor, send it back to factory for inspection.

5. PARAMETER LIST :

Code	Function	Range		Default	Unit	Description
		Min.	Max.			
tS	setpoint	LS	HS	4 40	°C °F	Compressor stops when it reaches the setpoint.
td	Setpoint differential	0.5 1	10 20	4 8	°C °F	Compressor will be on when the temp. \geq tS + td.
dF	Defrost cycle	0	99	6	hr	Set the interval of defrost period.
dt	Defrost period	1	55	30	min	To control defrost time, the system would stop defrosting if defrost time is run out.
AU	Max. temperature alarm	AL+1 131	50 113	45 113	°C °F	Alarm outputs (Buzzer) when room temperature is higher than or equal to the setting value. (To operate: cabinet temperature needs to be up to setting temperature once)
AL	Min. temperature alarm	-40	AU-1	-40	°C °F	Alarm outputs (Buzzer) when room temperature is lower than or equal to the setting value. (To operate: room temperature needs to be up to setpoint once)
HS	Max. setpoint	tS	45 111	25 79	°C °F	To limit the max. setpoint.
LS	Min. setpoint	-40	tS	-30 -20	°C °F	To limit the min. setpoint.
Ad	Alarm delay	0	60	15	min	Buzzer output delay time when alarming.
AC	Compressor delay protection	0	30	1	min	Interval of protection time for compressor operation
Cr	Compressor operation period under any failure	0	60	15	min	Compressor operation time when EE or E1 blinks.
CS	Compressor termination period under any failure	0	60	15	min	Compressor termination time when EE or E1 blinks.
Ot	Temperature calibration	-12 -20	12 20	0 0	°C °F	Cabinet temperature calibration.
Ut	Unit selection	°C	°F	°C		To display temperature unit.
OU	Exit setting	-	-	-		To quit setup mode.