



860CN 主控面板
 Central-Control Panel


TO_SCP : 860A 連接端子
 COMM1 : 860CN 連接端子
 COMM2 : 電源板並接端子
 P6 : 860CN 電源

※安裝注意事項：

1. 安裝前，請詳閱說明書。
2. 安裝時，請確認總電源已關閉。
3. 請做好控制器防水處理，以避免燒毀。
4. 送電前，請確認配線及輸入電源是否正確。
5. 確實遵循接點容量限制，以避免危險。
6. 若因裝配不當造成的故障，不在本公司保固範圍內。
7. DI高低壓保護開關輸入。

TO_SCP : 860A connecting terminal
 COMM1 : 860CN connecting terminal
 COMM2 : power board parallel terminal
 P6 : 860CN power

※Attention for Installation :

1. Please read the instruction carefully before installment.
2. Please make sure the central power is switched off.
3. To avoid any burned out , please treat well the waterproof of the controllers.
4. Please make sure the wiring and the power supply is correct before turning on the power.
5. Please do pay attention to the limitation of electronic capacity for each connecting point in order to avoid danger arised.
6. Any damage caused by improper operation or installment is beyond the manufacturer's warranty.
7. DI input terminal for compressor pressure protecting switch.

本產品由通過 ISO-9001 之公司研發・製造
 This product is Researched/Developed & Produced
 by Taiwan DEI company with ISO-9001 certification.