

DEI-617SE/617DE/817E Operation Manual

Version 05

5INSL00448

1. CAUTION :

- 1.1 Before wiring, please make sure that power is switched off to prevent from getting electric shock.
- 1.2 The product should be avoided to install at humid environment.
- 1.3 To prevent the controller burning out, please make sure the water-proofed procedure is undertaken during installation.
- 1.4 Please install according to the wiring diagram, in order to avoid incorrect wiring.
- 1.5 Before supplying the power, please always check if the wiring and input power is connected correctly.
- 1.6 Please always read this instruction carefully before installation. If the damage is caused of incorrectly wiring, the product would not be guaranteed.

2. SPECIFICATION :

2.1 Dimension :

- 2.1.1 Front panel size : 40mm (H) × 170mm (W) ± 1mm
- 2.1.2 Mounting hole size : 33mm (H) × 140mm (W) ± 1mm

2.2 Operating environment : -5°C ~ 55°C (23°F ~ 131°F), RH 20% ~ 85% (non - condensing)










2.3 Storage environment : -10°C ~ 65°C (14°F ~ 149°F), RH 20% ~ 85% (non - condensing)

2.4 Output/Input :


- 2.4.1 Power supply : AC 230 / 115V ± 10%, single phase 50 / 60Hz.
- 2.4.2 Power consumption : Max. 10 Watts (controller only)
- 2.4.3 Temperature display range : -45°C ~ 45°C ± 1°C (-45°F ~ 99°F ± 1°F)
- 2.4.4 Temperature sensor : NTC, PVC, 1.5M (L)
- 2.4.5 Compressor contact capacity : 25(7)A / 250VAC
- 2.4.6 Defrost contact capacity : 25A / 250VAC
- 2.4.7 Fan contact capacity : 7A / 250VAC
- 2.4.8 Lighting contact capacity : 7A / 250VAC
- 2.4.9 Defog contact capacity : 7A / 250VAC

3. FUNCTION :

3.1 Button operation :

- 3.1.1 Power ON / OFF : Press  and hold it for 3 seconds to startup the controller and it will operate with the setting mode and parameters automatically. Press this button again and hold it for 3 seconds to switch off the controller.
- 3.1.2 Light ON / OFF : Press  and hold it for 3 seconds to switch or the light.
- 3.1.3 Defog ON / OFF : Press  and hold it for 3 seconds to switch on or off the defog function.
- 3.1.4 Defrost : Press  and  and hold them for 3 seconds to enter defrost mode. Defrost process will be terminated automatically when reaches the defrost time or by pressing again both  and  buttons.
- 3.1.5 Lock / unlock parameters : In normal operation mode, press  and  and hold them for 3 seconds to lock the parameters, if "00" is displayed, or to unlock if "33" is displayed. (No any setting modification is allowed after locking the parameters)




3.1.6 User' s parameter setup :

Press  and hold it for 5 seconds to enter the user' s parameter setup mode, and the Set Temp. LED is on.

3.2 Function instruction :

3.2.1 Operation : The compressor starts operation when room temperature \geq (setting temperature + temperature differential), and compressor stops operation when room temperature \leq (setting temperature + temperature differential) or in defrost process.

3.2.2 Setup mode :

- 3.2.2.1 Press  to select sequentially from the functions, Set temp., Temp. differential, Defrost cycle, Defrost period, Temp. calibration, Compressor delay protection, Max. set temp. and Min. set temp.
- 3.2.2.2 When the required function is selected, press  and  to adjust the values.

3.2.2.3 If no more button is pressed within 10 seconds, the controller will save the new parameters and values and back to the normal operation mode.

3.2.3 Defrost mode and fan operation :

3.2.3.1 Compressor-off defrost (DEI-617) :

- 3.2.3.1.1 Defrost is performed by the preset operation duty or forced manually. When defrost in progress, the Defr. LED blinks, compressor is off and fan keeps running.
- 3.2.3.1.2 After defrost, compressor operates according to the difference between room temperature, setting temperature and temperature differential.

3.2.3.2 Electrical heater defrost (DEI-817) :

- 3.2.3.2.1 Defrost is performed by the preset operation duty or forced manually. When defrost in progress, the Defr. LED blinks, compressor is off and heater turns on and fan stops.
- 3.2.3.2.2 After defrost, fan starts with two minutes delay and compressor with one minute delay, operates according to the difference between room temperature, setting temperature and temperature differential.

3.2.4 Even the compressor delay protection is setup for 0 minute, compressor will still operate one minute delay after power is supplied.

3.2.5 When the room sensor is in failure, compressor operates cyclically every 15 minutes.

3.3 Indicator/symbol :

| Function | Indicator (● : ON, ○ : OFF, ⊙ : Blinking) | | | | | |
|--------------------------------|---|----------|-----------|------------------|---------------|----------------|
| | Defog | Lighting | Set temp. | Set differential | Defrost cycle | Defrost period |
| Set temp. (Room) | ○ | ○ | ● | ○ | ○ | ○ |
| Temp. differential | ○ | ○ | ○ | ● | ○ | ○ |
| Defrost cycle | ○ | ○ | ○ | ○ | ● | ○ |
| Defrost period | ○ | ○ | ○ | ○ | ○ | ● |
| Temp. calibration (Room temp.) | ⊙ | ○ | ● | ○ | ○ | ○ |
| Compressor delay protection | ⊙ | ○ | ○ | ● | ○ | ○ |
| Max. set point | ⊙ | ○ | ○ | ○ | ● | ○ |
| Min. set point | ⊙ | ○ | ○ | ○ | ○ | ● |

3.4 Parameter table :

| Function | Minimum | Maximum | Default |
|--------------------------------|----------------|----------------|---|
| Set temp. (Room) | Min. set point | Max. set point | -18°C / 0°F (DEI-817E) 5°C / 41°F (DEI-617SE/DE) |
| Temp. differential | 1°C / °F | 10°C / °F | 4°C / °F |
| Defrost cycle | 0 HR | 99 HR | 6 HR |
| Defrost period | 0 MIN. | 59 MIN. | 30 MIN. |
| Temp. calibration (Room temp.) | -8°C / °F | 7°C / °F | 0°C / °F |
| Compressor delay Protection | 0 MIN. | 15 MIN. | 3 MIN. |
| Max. set point | Set temp. | 40°C / 90°F | 40°C / 90°F |
| Min. set point | -40°C / -40°F | Set temp. | -40°C / -40°F |

4. ERROR CODES :

- 4.4 "EE" : Parameter memory failure (Re-plug in and operate as factory default)
- 4.5 "E1" : Sensor probe failure (Check if the sensor is well connected or replace a new sensor)